9/17

F1G. 94

PROGRAM LOAD

STEP EXECUTION

WRITE TO STEP EXECUTION ENABLE

BIT OF CONTROL REGISTER

+GO

HINL

Please add i+

INTERNAL REGISTER READ ( C) MONITOR RAM ON MEMORY MAP F16.9C

FIG. 9D BREAKPOINT SETTING

WRITE TO BREAK ENABLE BIT AND BREAK ADDRESS BIT OF CONTROL REGISTER



11/17 (con't)

